# General **Specifications**

GS 01C31Y01-01EN

EJAC60E

Hygienic Adapter System (Fluidless Type) EJA560E

Hygienic Gauge Pressure Transmitter (Fluidless Type)

DP harp **EJ** 

[Style: S2]

EJAC60E Hygienic Adapter System (Fluidless Type) consists of EJA560E Hygienic gauge pressure transmitter (Fluidless Type) and C10SA Hygienic adapter with various kind of process connections, and outputs a 4 to 20 mA DC signal corresponding to the measured pressure.

It also features quick response, remote setup and monitoring via HART communications and selfdiagnostics.

### **Process connection style**

- ISO 2852 Clamp
- ISO 2853 Union
- DIN 11851 Union
- GV In-line Clamp
- GV Clamp

#### **Features**

Strain resistor type, no silicon resonator. High temperature: 150°C continuously

Quick response: 120 ms

High performance: Remote setup and monitoring via

HART and self diagnostics

Burst Pressure: 25 MPa (3600 psi)

EJAC60E represents a Hygienic Adapter System type.

CE marking and other certification are acquired for model code of EJA560E transmitter.

See section "MODEL AND SUFFIX CODES" of this document.

Hygienic Adapter System (Fluidless Type)	Applicable Transmitter	
EJAC60E	EJA560E	

### ■ STANDARD SPECIFICATIONS

### SPAN AND RANGE LIMITS

1	easurement pan/Range	MPa	psi (/D1)	bar (/D3)	kgf/cm² (/D4)
A	Span	20 to 400 kPa	2.9 to 58	0.2 to 4	0.2 to 4
	Range	-100 to 400 kPa	-14.5 to 58	-1 to 4	-1 to 4
В	Span	0.1 to 1	14.5 to 145	1 to 10	1 to 10
	Range	-0.1 to 1	-14.5 to 145	-1 to 10	-1 to 10
С	Span	0.3 to 3	43.5 to 435	3 to 30	3 to 30
	Range	-0.1 to 3	-14.5 to 435	-1 to 30	-1 to 30

\*: Hygienic clamps usually have a withstand pressure of 1 MPa (145 psi). If applied pressure exceed 1 MPa (145 psi), clamps with pressure resistance over 1 MPa (145 psi) is nessesary.



## □ PERFORMANCE SPECIFICATIONS

Zero-based calibrated span and linear output, unless otherwise mentioned.

#### **Specification Conformance**

EJA-E series ensures specification conformance to at least +3σ

## Reference Accuracy of Calibrated Span

(includes the effects of terminal-based linearity, hysteresis, and repeatability)

Measurement		Reference Accuracy
span	Span≥X	Span <x< th=""></x<>
Α	±0.15% of Span	±(0.0375 URL/span)% of Span
В		±(0.045 URL/span)% of Span
С	Орап	±(0.025 URL/span)% of Span

Measurement span	Α	В	С
Х	100 kPa	0.3 MPa	0.5 MPa
	(14.5 psi)	(43.5 psi)	(72.5 psi)
URL	400 kPa	1 MPa	3 MPa
(Upper range limit)	(58 psi)	(145 psi)	(435 psi)

### Ambient Temperature Effects per 28°C (50°F) Change (All capsules)

±(0.28% of Span + 0.28% of URL)

## **Process Temperature Effects** Steady State (All capsules)

±(0.1% of URL) per 10°C (18°F) Change

## Transient State \*

±(8% of URL) for A capsule.

±(4% of URL) for B and C capsule.

- Reference value (this is not a guaranteed value). According to the results of the cold and hot water (temperature difference 90 ±5°C) evaluation test.
- If the measurement span is small, a setting of 10 or more seconds for the damping time constant is recommended. The output may temporarily exceed the setting range when the temperature of the measured rises rapidly.

(Damping time constant can be specified by option code CA.)



# Stability (All normal operating condition)

±0.2% of URL for 1 year

## **Power Supply Effects**

±0.005% per Volt (from 21.6 to 32 V DC, 350Ω)

#### **Vibration Effects**

Less than 0.1% of URL when tested per the requirements of IEC60770-1 field with general application or pipeline with low vibration level (10-60 Hz, 0.15 mm displacement/60-2000 Hz 2g)

### **Mounting Position Effects**

Rotation in diaphragm plane has no effect. Tilting up to 180 degree will cause zero shift up to  $\pm 0.1$  kPa (0.4 in H<sub>2</sub>O) which can be corrected by the zero adjustment.

### Response Time (All capsules)

120 ms

When software damping is set to zero and including dead time of 60 ms (nominal)

## FUNCTIONAL SPECIFICATIONS

## Output

Two wire 4 to 20 mA DC output with digital communications, linear or square root programmable. HART FSK protocol is superimposed on the 4 to 20 mA signal.

Output range 3.6 mA to 21.6 mA Output limits conforming to NAMUR NE43 can be pre-set by option code C2 or C3.

#### Failure Alarm

Output status at CPU failure and hardware error; Up-scale: 110%, 21.6 mA DC or more (standard) Down-scale: -5%, 3.2 mA DC or less

## **Damping Time Constant (1st order)**

Amplifier's damping time constant is adjustable from 0.00 to 100.00 s by software and added to response

## **Update Period**

Pressure: 60 ms

### **Zero Adjustment Limits**

Zero can be fully elevated or suppressed, within the lower and upper range limits of the capsule.

## **External Zero Adjustment**

External zero is continuously adjustable with 0.01% incremental resolution of span. Re-range can be done locally using the digital indicator with range setting switch.

### Integral Indicator (LCD display, optional)

5-digit numerical display, 6-digit unit display and bar graph

The indicator is configurable to display one or up to three of the following variables periodically; pressure in %, scaled pressure, measured pressure. See also "Factory Settings."

### **Local Parameter Setting**

Parameter configuration by the external zero adjustment screw and push button (Integral indicator code E) offers easy and quick setup for parameters of Tag number, Unit, LRV, URV, Damping, Output mode (linear/square root), Display out 1, and Re-range by applying actual pressure (LRV/URV).

#### **Burst Pressure Limits**

25 MPa (3600 psi)

- \*: Wetted parts may be destroyed and process fluid is leaks out when exceeding burst pressure.
- \*: Required to confirm whether pressure exceed 1 MPa (145 psi) or not. (Normal sanitary clamp has a withstand 1 MPa (145 psi).)

### **Self Diagnostics**

CPU failure, hardware failure, configuration error, process alarm for pressure or capsule temperature. User-configurable process high/low alarm for pressure is available.

### Signal Characterizer

User-configurable 10-segment signal characterizer for 4 to 20 mA output.

#### Lightning protector

EJA560E adopts a lightning protector as standard. Allowable current: Max. 6000 A (1×40 μs), Repeating 1000 A (1×40 μs) 100 times Applicable Standards: IEC 61000-4-4, IEC 61000-4-5

## NORMAL OPERATING CONDITION (Optional features or approval codes may affect limits.)

#### **Ambient Temperature Limits**

-40 to 85°C (-40 to 185°F) (General) -30 to 80°C (-22 to 176°F) (With LCD display) For relationship between process temperature, see Figure 1


## **Process Temperature Limits**

-20 to 150°C (-4 to 302°F)

For relationship between ambient temperature, see Figure 1

The ambient temperature below 33°C (91.4°F) is become unlimited at 150°C (302°F).

The ambient temperature between 33°C (91.4°F) and 70°C (158°F) are become limited at 150°C (302°F) per 60 minute.



 \* Available for 1 hour continuously at process temperature 150°C (302°F) and ambient temperature 45°C (113°F)

Figure 1. Relationship Between Ambient Temperature and Process Temperature

### Ambient Humidity Limits 0 to 100% RH

#### **Maximum Over Pressure**

Capsule	Pressure
Α	2 MPa (290 psi)
В	5 MPa (720 psi)
С	7.5 MPa (1080 psi)

<sup>\*:</sup> Calibration is needed once pressure exceed maximum over pressure.

### **Working Pressure Limits**

0.00 kPa abs (Without Degree of Vacuum Limit) to URL (Upper Range Limit)

## Behavior with regards to Over Pressure

Applied pressure also include maximum momentary pressure (surge pressure). The measurement method of this sensor is pressure detection using strain of metal diaphragm. The maximum momentary pressure exceeding the above pressure affects the characteristics of the sensor. The causes of the momentary pressure (surge pressure) are considered as follows:

- Surge pressure of bubbly mixed fluid when installed to the upper end of the pipe (Figure 2)
- Inrush pressure when installed to the bending pipe (Figure 3)
- Water hammer
- Steam explosion by steam and water contact (Figure 4)
- Direct washing of sensor with washing nozzle (Figure 5)

Concerning installation, please take the above contents into consideration while installing.




Figure 2. Surge Pressure of Bubbly Mixed Fluid When Installed to the Upper End of the Pipe




Figure 3. Inrush Pressure When Installed to the Bending Pipe




Figure 4. Steam Explosion by Steam and Water Contact




Figure 5. Direct washing of Sensor with Washing Nozzle

## Supply & Load Requirements

With 24 V DC supply, up to  $550\Omega$  load can be used. See graph below.




Figure 6. Relationship Between Power Supply Voltage and External Load Resistance

## Supply Voltage

10.5 to 42 V DC

Minimum voltage limited at 16.6 V DC for digital communication, HART

#### Load

0 to 1290  $\Omega$  for operation 250 to 600  $\Omega$  for digital communication

## **Hygienic Standards**

3-A Sanitary Certification \*

\*: Not applicable with GV Clamp DN40.

### **EMC Conformity Standards**

EN 61326-1 Class A, Table2 EN 61326-2-3

### **EU RoHS Directive**

EN IEC 63000

## Safety Requirements Standards

EN 61010-1

- Installation category: I (Anticipated transient overvoltage 330 V)
- Pollution degree: 2Indoor/Outdoor use

# SIL Certification

None

### PHYSICAL SPECIFICATIONS

## Wetted Parts Materials

## Diaphragm

Duplex stainless steel

#### The others

316L SST

## O-ring

EPDM (Ethylene-propylene rubber) or FKM (Fluoro-rubber)

#### Gasket

EPDM (Ethylene-propylene rubber) or FKM (Fluoro-rubber)

### **Non-wetted Parts Materials**

#### Housing

- Low copper cast aluminum alloy
- Stainless steel

### **Coating of Housing**

[for aluminum housing]

Polyester resin powder coating Mint-green paint (Munsell 5.6BG 3.3/2.9 or its equivalent)

[for option code /P□ or /X2]

Epoxy and polyurethane resin solvent coating

## **Degrees of Protection**

IP66/IP67, Type 4X

## **Pipe**

Polyamide

## **Cover O-rings**

[for aluminum housing]

Buna-N, fluoro-rubber (optional)

[for stainless housing]

Silicon

## Name Plate and Tag

316 SST or Polyester Label \*

\*: for amplifier housing code 5 or option code /3A

### Clamp

304 SST or SCS 13

## **Coupling Nut**

304 SST

### Weight \*

[for aluminum housing]

1.3 kg (2.9 lb)

[for stainless housing]

1.4 kg (3.0 lb) \*: Without int

\*: Without integral indicator, with ISO 25/38 clamp

#### Connections

Refer to "MODEL AND SUFFIX CODES."

#### < Related Instruments >

FieldMate Versatile Device Management Wizard: Refer to GS 01R01A01-01E.

Power Distributor: Refer to GS 01B04T01-02E or GS 01B04T02-02E

### < Reference >

- DPhap EJA\*; Registered trademark or trademark of Yokogawa Electric Corporation.
- FieldMate; Registered trademark or trademark of Yokogawa Electric Corporation.
- HART®; Registered trademark of FieldComm Group.


Other company names and product names used in this material are registered trademarks or trademarks of their respective owners.

## ■ MODEL AND SUFFIX CODES

The model codes of Hygienic Adapter System (Fluidless Type) consist of a transmitter part and an adapter part. Various kinds of products can be realized by combining a transmitter with an adapter.

This sheet describes the codes of the hygienic adapter system, a transmitter part and an adapter part.

## **EJAC60E** Hygienic Adapter System (Fluidless Type)



## Hygienic Adapter System (Fluidless Type)

Combination Model	Suffix Codes		s	Description		
EJAC60E					Hygienic Adapter System (Fluidless Type)	
Measurement type	-G				Gauge Pressure	
Style	6				Hygienic Adapter	
	0				Always 0	
Measurement Sp	an 🗆				Select from measurement span (capsule) codes of the transmitter (A, B or C)	
Process Connect	U			Clamp connection type Union connection type In-line clamp connection type		
Wetted parts		J			Select from wetted parts materal codes of the adapter. (Wetted parts material codes: S)	
		Ν			Always N	
N			Always N			
Fill fluid N			(None)			
N		-N	Always N			
				N	Always N	

### **Transmitter part**

## **EJA560E Hygienic Gauge Pressure Transmitter (Fluidless Type)**




Model	Suffix Code	es	Description
EJA560E			Hygienic Gauge Pressure Transmitter (Fluidless Type)
Output signal	-J		4 to 20 mA DC with digital communication (HART 5 / HART 7 protocol) (Refer to GS 01C31T01-01EN)
Measurement spa (capsule)	B		20 to 400 kPa (2.9 to 58 psi) 0.1 to 1 MPa (14.5 to 145 psi) 0.3 to 3 MPa (43.5 to 435 psi)
Wetted parts mater	al *1*8 <b>E</b>		[Diaphragm] [Others] 329J4L SST *2 316L SST *3
Connection type	H		G3/4 male connection
	N		Always N
Wetted O-ring *5			EPDM (Ethylene-propylene rubber) FKM (Fluoro-rubber) *4
Amplifier housing			Cast aluminum alloy Stainless steel
Electrical connect	2 4 5 7 9 A C D		G1/2 female, one electrical connection without blind plugs 1/2 NPT female, two electrical connections without blind plugs *6 M20 female, two electrical connections without blind plugs *6 G1/2 female, two electrical connections with a blind plug *6 1/2 NPT female, two electrical connections with a blind plug *6 M20 female, two electrical connections with a blind plug *6 G1/2 female, two electrical connections and a 316 SST blind plug *6 1/2 NPT female, two electrical connections and a 316 SST blind plug *6 M20 female, two electrical connections and a 316 SST blind plug *6 1/2NPT female, one electrical connection without blind plugs *7 M20 female, one electrical connection without blind plugs *7
Integral indicator	·	DEN	Digital indicator with the range setting switch (push button)
		N	Always N
Optional Codes		/□	Optional specification

Most typical selection for each specification ex. EJA560E-JAEHN-E10NN/D

- Users must consider the characteristics of selected wetted parts material and the influence of process fluids. The use of inappropriate materials can result in the leakage of corrosive process fluids and cause injury to personnel and/or damage to plant facilities. It is also possible that the diaphragm itself can be damaged and that material from the broken diaphragm can contaminate the user's process fluids.
  - Be very careful with highly corrosive process fluids such as hydrochloric acid, sulfuric acid, hydrogen sulfide, sodium hypochlorite, and high-temperature steam (150°C [302°F] or above). Contact Yokogawa for detailed information of the wetted parts material.
- Equivalent to SUS329J4L
- SUS316L or ASTM grade 316L
- \*4: Lower limit of ambient temperature: -20°C (-4°F)
- \*5:
- 3-A Sanitary Certification.

  Not applicable for amplifier housing code "5" \*6:
- Not applicable for amplifier housing code "1"
- Surface roughness for wetted part: Ra ≥ 0.8 µm

## C10SA Hygienic Adapter



Model		Suffix Codes			Description	F09E.
C10SA	<del></del>		. Hygienic Adapter	Description		
System location	<del> </del>		+			
Process Connection Style	on Style U		Clamp connection Union connection			
Usage				<del>'</del>		
Adapter material'		S		1		
Process Connect		S		. ISO . DIN		
Process Connection Size  8		 . ISO25/38 (IDF1.0S/1.5S)*6 . ISO51 (IDF2.0S) . ISO63.5 (IDF2.5S) . ISO76.1 (IDF3.0S)	[DIN type] DIN25 DIN32 DIN40 DIN50	[GV type] DN25 DN40 DN40/50 DN65/80 DN100		
Sealing Face Opt	4    Sealing Face Option			Electro polishing *2  Buffing *3  Electro polishing and Buffing  None	<b>1</b> *2*3	2
				<del>- '</del>		
		N		. Always N	,	
		N		Always N		
		N.		. Always N		
		1	١	. Always N		
Accessories *4*9		-2 -1	ISO38 (IDF1.5S) ISO51 (IDF2.0S) ISO63.5 (IDF2.5S) ISO76.1 (IDF3.0S) ISO101.6 (IDF4S)	[DIN type] DIN25 DIN32 DIN40 DIN50 		
			G	(Clamp Maximum Worki ISO2853 Coupling Nut (Maximum Working Pres DIN11851 Coupling Nut (Maximum Working Pres	ng Pressure: 1 MPa ( ssure: 3 MPa (435 psi	j))
			N	. Always N		,
	Gasket material *8		E	. EPDM (Ethylene-propylene	rubber)	

- SUS316L or ASTM grade 316L. Electro polishing for all wetted parts. Buffing for wetted part. (JIS-standard: #400) \*1: \*2: \*3: \*4: \*5: \*6: \*7: \*8: \*9:
- Clamp and gasket are not required, all of the code are selected "N".
- All the code of Clamp and gasket can be selected only "N". The code "6" of union nut can be selected only ISO38. Lower limit of ambient temperature: -20°C (-4°F) 3-A sanitary standard.

- Combination is listed in the accessary list.
- Surface roughness for wetted part: Ra ≥ 0.8 µm

# **OPTIONAL SPECIFICATIONS**

## • EJAC60E Hygienic Adapter System (Fluidless Type)

Item	Description	
Oil-prohibited use	Degrease cleansing treatment	K21
Oil-prohibited use with dehydrating treatment	Degrease cleansing and dehydrating treatment	K25

## • EJA560E Hygienic Gauge Pressure Transmitter (Fluidless type)

Item		Description				
Painting *8	Color change	Amplifier cover only				
		Amplifier cover and terminal cover, Munsell 7.5 R4/14			PR	
	Coating change	Anti-corrosion coating *	Anti-corrosion coating *1			
316 SST ex	terior parts *2	316 SST zero-adjustme	ent screw and setscrews	5	НС	
Fluoro-rubb	er O-ring *8	All O-rings of amplifier	housing. Lower limit of a	mbient temperature: –15°C (5°F)	HE	
Oil-prohibite	d use	Degrease cleansing tre	eatment		K11	
		Degrease cleansing tre	eatment and certificate		K81	
Oil-prohibite dehydrating		Degrease cleansing an	nd dehydrating treatment		K15	
Wired tag pl	ate *8	316 SST tag plate wire	d onto transmitter		N4	
Output limits operation *3	and failure	Failure alarm down-scale: Output status at CPU failure and hardware error is -5%, 3.2 mA DC or less for 4 to 20 mA output type and -5%.			C1	
		NAMUR NE43 Compliant	Failure alarm down-scale: Output status at CPU failure and hardware error is -5%, 3.2 mA DC or less.		C2	
		Output signal limits: 3.8 mA to 20.5 mA	Failure alarm up-scale: error is 110%, 21.6 mA	Output status at CPU failure and hardware or more.	C3	
Data configu	ration at factory *4	Data configuration for I	HART communication ty	pe, Software damping, Descriptor, Message	CA	
Calibration (	units *5	P calibration (psi unit)			D1	
		bar calibration (bar unit	:)	(See Table for Span and Range Limits.)	D3	
		M calibration (kgf/cm² unit)			D4	
Material cer	tificate	Diaphragm, Body			M16	
High-humiditype *7	ty environment	Atmospheric release from terminal box *6 Lower limit of ambient temperature: -15°C (5°F)		нн		
Sanitary sta	ndard *9	3-A Sanitary Certification			3A	
Parameter I	st	List of setting and adjus	stment parameters		YP	

- Not applicable with color change option.
- 316 or 316L SST.
- \*1: \*2: \*3: \*4: The hardware error indicates faulty amplifier or capsule.
- Also see 'Ordering Information'.
  The unit of MWP (Max. working pressure) on the name plate of a housing is the same unit as specified by option codes D1, D3, and D4.
- When chose option code HH, the L-side hole of body is sealed with a sealing screw and the reference pressure (atmospheric pressure) is introduced from the terminal box of the amplifier housing.

  In the standard specification, the reference pressure (atmospheric pressure) is introduced from the L-side hole of body.
- Not applicable with Electrical connection code "0" of transmitter.
- Not applicable for amplifier housing code 5.
- Not applicable with GV Clamp DN40.

# • C10SA Hygienic Adapter

Item	Description	Code
Oil-prohibited use	Degrease cleansing treatment	K31
	Degrease cleansing treatment and certificate	K81
Oil-prohibited use with dehydrating treatment	Degrease cleansing and dehydrating treatment	K35
Material certificate	Adapter	M17
Certificate	Electro polishing	Y1
	Buffing	Y2
	Buffing and Electro polishing	Y4

## **Notes for Combination**


Process Connection Style	Process Connection Standard	Process Connection Size
С	S	6, 2, 1, 3, 4
	V	6
11	S	6, 2
	D	8, 7, 6, 2
D	V	8, 2, 3, 4

## **■ DIMENSIONS**

## **EJA560E** Hygienic Gauge Pressure Transmitter (Fluidless Type)


Unit: mm (approx. inch)


· Cast aluminum housing



\*1: When electrical connection code 7 or C is selected, a blind plug is protruded by up to 8 mm from conduit connection.

Electrical connection for code 5, 9, A, and D.






Dimensions					
Measurement span code	øΑ				
Α	10(0.39)				
B, C	8(0.31)				
	•				

Cross section dimensions of diaphragm

## • Terminal Configuration



## Terminal Wiring

SUPPLY +	① Power supply and output terminals		
CHECK +	③ External indicator (ammeter) terminals*1		
Ground terminal			


<sup>\*1:</sup> When using an external indicator or check meter, the internal resistance must be 10  $\Omega$  or less.


F10E.ai

11

# **EJA560E** Hygienic Gauge Pressure Transmitter (Fluidless Type)


Unit: mm (approx. inch)





Cross section dimensions of diaphragm

## • Terminal Configuration



## • Terminal Wiring

SUPPLY +	Power supply and output terminals		
CHECK +	③ External indicator (ammeter) terminals*1		
- Ground terminal			


<sup>\*1:</sup> When using an external indicator or check meter, the internal resistance must be 10  $\Omega$  or less.


F11E.ai


# C10SA Hygienic Adapter

Unit: mm (approx. inch)


# • ISO 2852 Clamp Connection








Process connection size for code 6



Enlarged view of wetted O-ring area except for code 6





Enlarged view of wetted O-ring area for code 6


F12E.ai

	Code	Adapter size	øΑ	øΒ	С
	6	ISO25/38	50.5 (1.99)	43.5 (1.71)	14 (0.55)
100 0050 01	2	ISO51	64 (2.52)	56.5 (2.22)	15.2 (0.60)
ISO 2852 Clamp Connection	1	ISO63.5	77.5 (3.05)	70.5 (2.78)	15.2 (0.60)
	3	ISO76.1	91 (3.58)	83.5 (3.29)	20 (0.79)
	4	ISO101.6	119 (4.69)	110 (4.33)	20 (0.79)

## • ISO 2853 Union Connection








Enlarged view of wetted O-ring area


F13E.ai

	Code	Adapter size	øA	øB	С
ISO 2853 Union	6	ISO38	47 (1.85)	42.5 (1.67)	15.2 (0.60)
Connection	2	ISO51	60.5 (2.38)	56.0 (2.20)	15.2 (0.60)

## • DIN 11851 Union Connection








Enlarged view of wetted O-ring area


Enlarged view of wetted O-ring area for code 8


F14E.ai

	Code	Adapter size	øΑ	øΒ	С	D
	8	DN25	44 (1.73)	27.5 (1.08)	14 (0.55)	21 (0.83)
DIN 11851 Union	7	DN32	50 (1.97)	33 (1.30)	15.2 (0.60)	21 (0.83)
Connection	6	DN40	56 (2.20)	39 (1.54)	15.2 (0.60)	21 (0.83)
	2	DN50	68.5 (2.70)	51 (2.01)	15.2 (0.60)	22 (0.87)

# • GV In-line Clamp Connection









Enlarged view of wetted O-ring area


F15E.ai

	Code	Adapter size	øΑ	øΒ	С	D
	8	DN25	66 (2.60)	50 (1.97)	15.2 (0.60)	9.5 (0.37)
GV In-line Clamp	2	DN40/50	84 (3.31)	68 (2.68)	20.2 (0.80)	12.1 (0.48)
Connection	3	DN65/80	115 (4.53)	94.9 (3.74)	22 (0.87)	15.2 (0.60)
	4	DN100	142 (5.59)	122.9 (4.84)	21.8 (0.86)	15.2 (0.60)

# • GV Clamp Connection







Enlarged view of wetted O-ring area

F16E.ai

	Code	Adapter size	øΑ	øB	С
GV Clamp Connection	6	DN40	66 (2.60)	55.2 (2.17)	15.2 (0.60)

## Accessary list

			Accessary		
Adapter Style	Adapter Size	Claren / Casseline Next	Gasket (3A)		
		Clamp / Coupling Nut	EPDM	FKM	
	ISO25/38	ISO25/38 Clamp	ISO25 ISO38	ISO25 ISO38	
ISO 2852	ISO51	ISO51 Clamp	ISO51	*	
Clamp	ISO63.5	ISO63.5 Clamp	ISO63.5	*	
	ISO76.1	ISO76.1 Clamp	ISO76.1	*	
	ISO101.6	ISO101.6 Clamp	ISO101.6	*	
ISO 2853	ISO38	ISO38 Coupling Nut	*	*	
Union	ISO51	ISO51 Coupling Nut	*	*	
	DIN DN25	DIN DN25 Coupling Nut	*	*	
DIN 11851	DIN DN32	DIN DN32 Coupling Nut	*	*	
Union	DIN DN40	DIN DN40 Coupling Nut	*	*	
	DIN DN50	DIN DN50 Coupling Nut	*	*	
	GV DN25	*	*	*	
GV	GV DN40/50	*	*	*	
In-line Clamp	GV DN65/80	*	*	*	
	GV DN100	*	*	*	
GV Clamp	GV DN40	*	*	*	

<sup>\*:</sup> We do not stock that product.
This should be prepared by users.

### < Ordering Information >

Specify the following when ordering

- 1. Model, suffix codes, and option codes
- 2. Calibration range and units
  - Calibration range can be specified with range value specifications up to 5 digits (excluding any decimal point) for low or high range limits within the range of -32000 to 32000. When reverse range is designated, specify Lower Range Value (LRV) as greater than Upper Range Value (URV).
  - 2) Specify only one unit from the table, 'Factory Settings' when shipped.'
- 3. Display scale and units (for transmitters equipped with integral indicator only) Specify either 0 to 100 % or engineering unit scale and 'Range and Unit' for engineering units scale: Scale range can be specified with range limit specifications up to 5 digits (excluding any decimal point) for low or high range limits within the range of -32000 to 32000. The unit display consists of 6-digit, therefore, if the specified unit is longer than 7 characters excluding '/', the first 6 characters will be displayed on the unit display.
- 4. HART PROTOCOL

Specify the HART protocol revision "5" or "7".

- 5. TAG NO (if required)
  - Specified characters (up to 22 characters or 16 characters for /N4 tag) are engraved on the stainless steel tag plate or polyester label fixed on the housing.
- 6. SOFTWARE TAG (if required)
  - Specified characters (up to 32 characters) are set as "Tag" (the first 8 characters) and "Long tag"\*1 (32 characters) in the amplifier memory. Use alphanumeric capital letters.
  - When the "SOFTWARE TAG" is not specified, specified "TAG NO" is set as "Tag" (the first 8 characters) and "Long tag"\*1 (22 characters) in the amplifier memory.
  - \*1: applicable only when HART 7 is selected.
- Other factory configurations (if required)
   Specifying option code CA will allow further configuration at factory. Following are configurable items and setting range.
  - 1) Descriptor (up to 16 characters)
  - 2) Message (up to 30 characters)
  - 3) Software damping in second (0.00 to 100.00)

### < Factory Setting >

Tag number	As specified in order
Software damping*1	'2.00 s' or as specified in order
Calibration range lower range value	As specified in order
Calibration range upper range value	As specified in order
Calibration range units	Selected from mmH <sub>2</sub> O, mmH <sub>2</sub> O(68°F), mmHg, Pa, hPa, kPa, MPa, mbar, bar, gf/cm <sup>2</sup> , kgf/cm <sup>2</sup> , inH <sub>2</sub> O, inH <sub>2</sub> O(68°F), inHg, ftH <sub>2</sub> O, ftH <sub>2</sub> O(68°F) or psi. (Only one unit can be specified)
Display setting	Designated value specified in order.(%, or user scaled value.)

<sup>\*1:</sup> To specify these items at factory, /CA option is required.

### < Information on EU WEEE Directive >

EU WEEE (Waste Electrical and Electronic Equipment) Directive is only valid in the EU.

This instrument is intended to be sold and used only as a part of equipment which is excluded from WEEE Directive, such as large-scale stationary industrial tools, a large-scale fixed installation and so on, and, therefore, subjected to the exclusion from the scope of the WEEE Directive. The instrument should be disposed of in accordance with local and national legislation/regulations.